



SINGER PARTS

Singer Knitting machines

For knitters outside of the UK you may wonder why your SINGER knitting machine is not listed. This is because in each country the Singer company had the right to put the Singer name on the knitting machine of their choice. So if your machine has a different Model number then its is likely to have come out of the factory that made other makes. Therefore make inquiries against the model number with the other well known makes.

- KE1200 (The pink machine) A flat bed single knitting machine sold under several names and was the first of the electronic punch card knitting machines. The card had a 12 stitch pattern width and the electronics were supplied by two batteries.
- KE2400 This was the first of the 24 stitch punch card machines. Ribber KR13
- KE 2500 An upgrade of the KE2400 Ribber KR13
- KE2600 An upgrade of the KE2500 Ribber KR13
- Model 400

To be completed later !